resultados uniformes y peinados perfectos. misma temperatura, lo que permite obtener Cada sección de cabello esta peinada usando la remperatura constante, sin perdida de calor. durante el uso, este sistema mantiene la de orras nerramientas cuya temperatura baja creadas por los ingenieros de Conair. A diferencia calor, igual que las herramientas profesionales está dotado de un sistema de conservación del cabello. Y esto no es todo... Su aparato también obtener los resultados deseados, sin lastimar el qesqe ei mas fino hasta ei mas grueso, siempre remperatura per ecta para su upo de cabello, was grueso, para permitine escoger ia an ribo de cabello, desde el más fino násta el bermitirle escoger la temperatura perfecta para Cuenta con 5 opciones de temperatura para constante durante el uso.

wiento muy rapido y mantiene la temperatura resistencia de ceramica que logra un calenta-Fare aparato esta dotado de una potente

SISTEMA DE CONSERVACION DEL CALOR & ARUTARAMAT AG SATSULA & САГЕИТАМІЕИТО ІИЅТАИТАИЕО,

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS **BEFORE USING** KEEP AWAY FROM WATER

DANGER - Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

- 1. Always unplug appliance immediately after using.
- 2. Do not use while bathing or in the shower. 3. Do not place or store appliance where it can

fall or be pulled into a tub or sink.

- 4. Do not place in, or drop into, water or other
- 5. If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING** To reduce the risk of burns,
- electrocution, fire, or injury to persons: 1. This appliance should never be left
- unattended when plugged in. 2. Do not pull, twist, or wrap line cord around appliance.
- 3. This appliance should not be used by, on or near children or individuals with certain disabilities.

beljecta para rizar su cabello facil y rapidaprincipio. Con práctica, encontrará la manera Zerá necesario experimentar un poco al cada sección.

ses uecessilo repetir el proceso varias veces en cadello. Segun la textura del cadello, puede que cabello. Repita el proceso con cada sección de cabelludo. Presione la manija para aflojar el cabello alrededor del tubo, hacia el cuero de cabello entre la pinza y el tubo. Enrolle el esbesol. Adra ias tenacilias y ponga una seccion bnjðsgs qe sucyo bor 1/5 bnjðsgs o meuos qe bejustlo. Divida el cabello en secciones de 1 loción fijadora ligera sobre el cabello antes de Para lograr resultados optimos, aplique una

'SO1NUIW

estática y el frizz.

apagará automáticamente después de 60

bnes tacilita el peinado y logra resultados

encenderio. Para su seguridad, ei aparato se

Nunca deje el aparato desatendido después de

Es un placer trabajar con esta nueva tecnologia,

ssjon. Además, no retiene el cabello despues de

cerámica/turmalina también ayuda a controlar la

Notará que el cabello se desliza fácilmente sobre

snave, el resultado de una tecnologia de punta.

nus caba de ceramica/turmaina increidiemente

El tubo de sus nuevas tenacillas está cubierto de

REVESTIMIENTO DE CERÀMICA/TURMALINA

ideal para uso en casa o cuando viaja. No deje el

Su aparato también incluye protector térmico que

le permitirà guardar el aparato aún caliente. Es

aparato conectado cuando no esté en uso.

peinados sedosos y brillantes, igual que en el

Distribuye el calor uniformemente, para crear

desbués de cada uso. El revestimiento de

ei tubo y que es muy tacil limpiar el aparato

(3° 004 – 4° 03E) xsM\otlA	Cabello resistente
(4° 0EE) otlA-oib9M	Cabello grueso u ondulado
(3° 01°) (F)	Cabello normal, espeso o tratado
Encendido/Bajo (285 °F)	Cabello delicado, fino o dócil
ARUTARAMAT AG SATSULA	TIPO DE CABELLO

Guia de temperatura

Personalice la temperatura, segun su tipo de dne ntilice un nivel de temperatura alto. grueso, ondulado o resistente, le recomendamos remperatura bajo. Si su cabello es espeso, recomendamos que utilice un nivel de rapidamente. Si su cabello es fino, le bara todo tipo de cabello, y calienta muy Fare abarato otrece 5 opciones de temperatura,

FUNCIONAMIENTO BÁSICO

4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

- 5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.
- 6. Keep the cord away from heated surfaces.
- Never use while sleeping.
- 8. Never drop or insert any object into any opening or hose.
- 9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- 10. Unit is hot when in use. Do not let heated surfaces touch eyes or skin.
- 11. Do not place the heated unit directly on any surface while it is hot or plugged in.
- 12. Never block the air openings of the appliance or place on a soft surface such as a bed or couch. where the air openings may be blocked. Keep the air openings free of lint and other debris.
- 13 Do not use an extension cord with this
- 14. Do not touch hot surfaces of the appliance. Use handles or knobs.
- 15. Do not attempt to touch the housing of your appliance near the barrel, as it is hot when

SAVE THESE INSTRUCTIONS

aparato. courscro cou la piei despues de encender el mente caliente en segundos. Evite todo ADVERTENCIA: El tubo se volverá extremadaaurante 30 segundos.

encendera. Permita que el aparato caliente aparato. La iuz de encendido/bajo (285 F) se cable en una toma de corriente. Encienda el FI cabello debe estar limpio y seco. Enchute el

FUNDAMENTOS DEL RIZADO

tunción de seguridad. electricista. No intente ir en contra de esta completamente, comuniquese con un corriente, inviértela. Si aún no entrara corriente polarizada. Si no entrara en la toma de enchufar de una sola manera en la toma de ofra). Como medida de seguridad, se podrà cjavija pojarizada (una pata es mas ancha que FI cable de este aparato esta dotado de una

(120V AC). con Corriente Alterna (60 Hz) de 120 voltios Para uso doméstico solamente. Uselo solamente

DE OPERACIÓN INSTRUCCIONES

Use on Alternating Current (60 hertz) only. This unit is designed to be operated at 120V AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do

INSTRUCCIONES **GUARDE ESTAS**

sire se vuelve muy callente durante el uso. No lo 15. El cuerpo del aparato cerca de la salida de sparato. Utilice el mango y los botones o perillas. 14. No toque las partes calientes de este 13. No utilice una extension con este aparato. beinasa, cabellos y elementos similares. obstruir. Mantenga las aberturas libres de

STYLING WITH THE NEW **TOURMALINE CERAMIC EASY-GLIDE BARREL** The barrel of your new curling iron has a

tourmaline ceramic easy-glide surface, the newest technology. This means it's not only simpler to clean off styling product residue, etc., after each use, but you'll find that hair glides easily over the surface of the barrel as you're curling. The tourmaline ceramic surface also helps smooth down flyaways and frizzies. It evenly distributes heat so that the style you create has a salon-perfect, silky smooth. shining finish. Hair also slips right through the barrel after it's curled.

The new Tourmaline Ceramic technology is a pleasure to work with and makes styling your hair easier and the results more professional.

Never leave your curling iron on and unattended. However, should you fail to turn the iron off, it will shut itself off automatically within 60 minutes.

como una cama o un sota, donde se puedan coloque el aparato en una superficie blanda,

superticie mientras estè caliente o conecta-11. No colodue el aparato en ninguna

12. Nunca bloquee las aberturas de aire ni

superticies calientes. Mantenga los ojos y la piel alejados de las 10. Este aparato se vuelve muy caliente. (sbray) o donde se este administrando oxigeno. qouqe se esten naando productos en aerosol

9. No lo utilice en exteriores, ni lo haga funcionar ninguna de las aberturas del aparato. 8. Munca deje caer ni inserte ningun objeto en dormido/a o adormilado/a.

7. Nunca utilice este aparato mientras esté

6. Mantenga el cable alejado de superficies

para su revisión y reparación. aparato a un centro de servicio autorizado caido o si estuviese danado. Regrese el unpiese funcionado mai o que se hubiese ciavila estuviesen danados, despues de que 5. No opere este aparato si el cordón o la

recomendados por el tabricante. según las instrucciones. Sólo use accesorios bropósito para el cual fue disenado y solamente 4. Utilice este aparato únicamente con el

cerca de ninos o personas con alguna discapaci-3. Este aparato no deberia ser usado por, sobre o alrededor del aparato.

2. No jale, retuerza ni enrolle el cable mientras este conectado. 1. Nunca deje el aparato desatendido

riesgo de quemaduras, electrocucion, incendio o ADVERTENCIA - Para reducir el

inmediatamente. No toque el agua.

5. Si el aparato cayera al agua, desconéctelo

4. No colodue el aparato ni lo deje caer al agua u

bnega caer o ser empujado a una bañera o un 3. No coloque ni guarde este producto donde

2. No lo use en el baño o la ducha.

mente después de usarlo. 1. Siempre desconecte el aparato inmediata-

Para reducir el riesgo de muerte o herida por bermanece bajo tension, aunque este apagado. PELIGRO - Cualquier aparato enchufado

ALEJADO DEL AGUA **MANTENGALO**

OJRAZU 30 SETNA INSTRUCCIONES **SAJ SAGOT A3J**

brecauciones básicas de seguridad, entre las mente en la presencia de niños, debe tomar Siempre que use aparatos electricos, especial-

IMPORTANTES SEGURIDAD MEDIDAS DE

USING INSTANT HEAT, THE 5 HIGH HEAT TEMPERATURE SETTINGS & UNIFORM HEAT RECOVERY SYSTEM

This styling iron features a ceramic heater that maintains constant temperature during use for precision styling.

This Instant Heat technology has 5 high heat temperature settings. There is a temperature range that's gentle and safe for every type of hair from the finest to the curliest and most resistant, and helps you create the look you want. And that's not all. Conair's professional salon standards of engineering provide you with a uniform and improved heat recovery system that maintains the iron at constant temperatures. There is a constant surge of power to ensure that heat is continuously and quickly delivered for optimal styling results, unlike other units which lose heat during use. This provides consistent styling power so that every strand of your hair is set with the same level of heat and comes out the same way for a perfect finish.

OPERATING INSTRUCTIONS

This curling iron is intended for household use.

not attempt to defeat this safety feature.

TO CURL HAIR

Hair should be clean and completely dried before using the curling iron. Plug the iron into an electrical outlet. Turn on unit. The Power/Low 285°F setting will become illuminated. Allow unit to heat up for 30 seconds.

WARNING: The curling iron's tourmaline ceramic-coated barrel will get very hot within a few seconds and should not be placed in contact with the skin after the curling iron has been turned on.

GETTING STARTED

The iron's unique 5 high heat temperature settings and Instant Heat technology provide styling versatility for all hair types. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-curl hair, keep the heat setting on high. You can vary the iron's temperature according to your particular need!

Temperature Setting Guide

LED TEMP. CONTROL	HAIR TYPE
Power/Low 285°F	Delicate, thin, easy-to-curl hair
Medium 310°F	Average-to-thick or treated hair
Med-High 330°F	Thick or wavy hair
High/Max 360°F - 400°F	Hard-to-curl hair

For best results, use a light styling product before blow-drying hair. Start curling with a hair section that is 1 inch wide and no more than 1/2 inch thick. Open the spoon and place a hair section on the barrel, rolling up, close to the scalp. Release the pressure on the handle and allow the hair section to slide out. Repeat process on additional sections of hair until you achieve the hair style you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

Some experience is necessary when learning to use this curling iron. After using the iron several times, you will learn the ideal way to curl and style your hair.

A bonus protective heat shield has been included to safely store product away when hot. Great for use at home or when traveling. Do not leave unit plugged in when not in use.



GETTING TO KNOW

YOUR CURLING IRON

Nano Tourmaline

Ceramic-coated Barrel

Heat Levels

Temperature

ON/OFF

with I FD

Displavs

Cool Tip

Counter Res

Temperature

Setting Buttons

Stainless

Steel Finish

Professional

Swivel Line Cord

Uniform Heat

30-second

Instant Heat

Auto Off

Recovery System

www.conair.com/infiniti ne sonetisiv o AIANOD-E-008-1 Conair o Infiniti by Conair¹⁷⁴, llame al:

Para más información sobre los productos

Glendale, AZ 85307 7475 N. Glen Harbor Blvd. Service Department ©2011 Conair Corporation

11PA121994

www.conair.com/registration Para registrar su producto, visitenos en:

que varian de un Estado a otro. especificos y usted puede tener otros derechos Esta garantía le otorga derechos legales weuciousqss bneden no regir para usted.

consecuentes, de modo que las limitaciones limitación de danos especiales, incidentales o Algunos Estados no permiten la exclusión o OTRA GARANTIA, EXPRESA O IMPLICITA. INCUMPLIMIENTO DE ESTA O CUALQUIER INCIDENTAL O CONSECUENTE DEBIDO AL CASO, POR NINGUN DANO ESPECIAL, CONAIR NO SERA RESPONSABLE, EN NINGUN

iss ilmitaciones mencionadas pueden no regir quración de una garantia implicita, de modo que Faggos no permiten limitaciones sobre la PRESENTE GARANTIA ESCRITA. Algunos LIMITADAS POR LOS 60 MESES DE LA PARA UN PROPOSITO ESPECIFICO, ESTARAN IMPLICITA DE COMERCIABILIDAD Y APTITUD PERO NO LIMITADAS A LA GARANTIA RESPONSABILIDAD IMPLICITAS, INCLUYENDO CUALQUIER GARANTÍA, OBLIGACIÓN O


a partir de la fecha de fabricación. compra, el periodo de garantia será de 60 meses instrucciones de envio. En ausencia del recibo de Ilamar al 1-800-3-CONAIR para recibir uecesitan dar una prueba de compra y deben manejo y envío. Los residentes de California sólo cheque o giro postal de US\$5.00 por gastos de al dorso, junto con su recibo de compra y un regrese su aparato al Centro de Servicio indicado Para obtener servicio técnico bajo esta garantia,

defectos de materiales o fabricación. bartir de la techa de compra si presentara sbarato sin cargo por un periodo de 60 meses a Conair reparará o remplazará (a su opción) su

GARANTIA LIMITADA DE CINCO ANOS

LOS APARATOS PEQUENOS SIEMPRE DESENCHUFE

eucunte los abaratos electricos desbues de hay corriente. Por lo tanto, siempre desanudne este apagado? Si esta conectado, nu sbarato electrico permanece bajo tension electricidad y el agua. Pero ¿Sabe usted que lodos sabemos que no se debe mezciar la



DEL AGUA MANTENGALO ALEJADO

ESTA EQUIVOCADO ATS3 ,00ADA9A9A EL APARATO ESTA CORRIENTE CUANDO SI CREE QUE NO HAY :ADVERTENCIA:

conecta al aparato este suelta y recta. bermita que el cable cuelgue o que la junta que lo eucunte: No envolle el cable alrededor del aparato. niños. No tironee ni retuerza el cable al nivel del lugar seco y seguro, tuera del alcance de los almacenar. Permita que enfrie y guárdelo en un Cuando no lo utiliza, su aparato es fácil de

ALMACENAJE


manera intermitente.

aparato dejara de funcionar o funcionara de iumediatamente si el cable parece danado o si el rse de que no esté dañado. Deje de usar el aparato ito. Revise el cable con frecuencia para aseguraaparato, produciendo su ruptura o un cortocircu-Esto boquis danar la junta flexible que lo conecta al Munca lo enrolle con fuerza alrededor del aparato. NUNCA Jale, retuerza ni doble mucho el cable.

NUIDUADAN

rrate de reparario. regréselo a un centro de servicio autorizado. No desconecte el aparato, permita que entrie y humedecido. En caso de mai funcionamiento, eutrie γ limpie la superticie exterior con un pano necesario limpiarlo, desenchúfelo, permita que aberturas libres de polvos y pelusas. Cuando sea necesita lubricación. Mantenga todas las Su aparato requiere poco mantenimiento. No

INSTRUCCIONES DE MANTENIMIENTO



SUS TENACILLAS FAMILIARICESE CON

INFINITIPE CONAR

nano tourmaline ceramic curling iron

Protector termico

brofesional

l in. (25 mm)Model CD107TP

AVAILABLE IN THE

FOLLOWING SIZES

 $1\frac{1}{2}$ in. (38 mm)Model CD109BP

USER MAINTENANCE

Your curling iron is virtually maintenance-free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

WARNING: IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

> **ALWAYS UNPLUG** SMALL APPLIANCES

LIMITED FIVE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 60 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on back, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 60 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABIL-ITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 60-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL. INCIDENTAL. OR CONSEQUEN-TIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Please register this product at: www.conair.com/registration

©2011 Conair Corporation Service Department 7475 N. Glen Harbor Blvd. Glendale, AZ 85307

For info on any Conair or Infiniti by Conair product call: 1-800-3-CONAIR or visit us

TALLAS DISPONIBLES:

Instruction & Styling Guide For your safety and continued enjoyment of this product, always read the instruction book carefully before using. Model CD106PRP

on the web at: www.conair.com/infiniti

IB-11007

11PA121994